

If you are concerned that you may have a Bosch dishwasher affected by the repair action, please call 1 800 322 222 to check if you have an affected model and arrange a repair. Affected models are listed below:

Brand	Dishwasher vib number
Bosch	SGS43C02GB
Bosch	SGS45E02GB
Bosch	SGS43A52GB
Bosch	SRS43C12GB
Bosch	SGS5342GB
Bosch	SGS43E02GB
Bosch	SGS43A12GB
Bosch	SGS45E08GB
Bosch	SRS43A02GB
Bosch	SRS4302GB
Bosch	SRS43C02GB
Bosch	SGS43E08GB
Bosch	SGS4332GB
Bosch	SRS46A02GB
Bosch	SRS43E02GB
Bosch	SRS45E02GB
Bosch	SGS53A02GB
Bosch	SGS5332GB
Bosch	SGS4442GB
Bosch	SGS43A18GB
Bosch	SGS5362GB
Bosch	SRS5602GB
Bosch	SGS8812GB
Bosch	SRS4312GB
Bosch	SGS5358GB
Bosch	SRS45E08GB
Bosch	SRS56A02GB
Bosch	SRS56A08GB
Bosch	SRS56L08GB
Bosch	SGS4468GB

Brand	Dishwasher vib number
Bosch	SRS56L02GB
Bosch	SRS8422GB
Bosch	SRS5612GB
Bosch	SGI5325GB
Bosch	SRS55L02GB
Bosch	SGS5348GB
Bosch	SGI43A25GB
Bosch	SGI56A05GB
Bosch	SGS4452GB
Bosch	SGI3302GB
Bosch	SGI43A22GB
Bosch	SGI43A26GB
Bosch	SGI5345GB
Bosch	SGI3300GB
Bosch	SRS53C02GB
Bosch	SGI3305GB
Bosch	SGI5326GB
Bosch	SGI56A06GB
Bosch	SGI5322GB
Bosch	SGI56A02GB
Bosch	SGI5342GB
Bosch	SGI5346GB
Bosch	SGI3312GB
Bosch	SGI3315GB
Bosch	SGI3316GB
Bosch	SGS45E62GB
Bosch	SGS45E68GB
Neff	S4443N6GB
Neff	S4453N1GB

Brand	Dishwasher vib number
Neff	S4443B6GB
Neff	S4456N3GB
Neff	S4443W6GB
Neff	S4453N2GB
Neff	S4433W0GB
Neff	S4433B0GB
Neff	S4433N0GB
Neff	S4456S3GB
Neff	S4453S1GB
Neff	S4433B1GB
Neff	S4456W3GB
Neff	S4453S2GB
Neff	S4453W1GB
Neff	S4433N1GB
Neff	S4433W1GB
Neff	S4453W2GB
Siemens	SE24233GB
Siemens	SE24237GB
Siemens	SF24T250GB
Siemens	SE25235GB
Siemens	SF24A262GB
Siemens	SE25831GB
Siemens	SF24A261GB
Siemens	SF25T550GB
Siemens	SE55A560GB
Siemens	SF24260GB
Siemens	SF24261GB
Siemens	SE55531GB
Siemens	SE54432GB
Siemens	SE54232GB